

Silicone-free furniture spray - 300 ml

GENERAL



Silicone-free furniture spray based on mineral oil.

- Cleans and nourishes wooden furniture.
- Removes scratches and stains.



Cleaning Power Mild

USAGE

- Shake well before use.
- Spray onto the surface and polish with a soft cloth.

Hazard statements:

H222: Extremely flammable aerosol.

H229: Pressurized container: may burst if heated.

H315: Causes skin irritation.

H336: May cause drowsiness or dizziness.

H412: Harmful to aquatic life with long lasting effects.

EUH066: Repeated exposure may cause skin dryness or cracking.

Only use this product for its specified purposes. If in doubt, first test the product in an inconspicuous area. BOMA is not responsible for any damages if the product is used incorrectly. Consult the Safety Data Sheet (SDS) for additional information.



READY TO USE

Silicone-free furniture spray - 300 ml

TECHNICAL SPECIFICATIONS

Dimensions product (HxØ) 23.5 x 5.5 cm

LOGISTIC DATA

Product

Article	210102
Unit	Spray
Gross weight	282 g
Net weight	290 g
EAN code	5411323010006

Packing

Quantity per packing	12
Dimensions	22 x 24.5 x 16.5 cm
Gross weight	3503 g
EAN code	05411323010013

Pallet

Quantity per pallet	1728
---------------------	------